{Learn, Create, Innovate};

Computer Vision

OpenCV





Computer Vision




- A sub field in computer science and artificial intelligence dedicated to identify and understand features in an image or video.
- Artificial intelligence mimics the thinking process.
 Computer vision aims to reproduce human sight and inference.
- Many modern learning-based techniques use computer vision as an entry node to perform inference methods:
 - · Artificial intelligence, machine learning, and deep learning





Computer Vision General Pipeline








Computer vision with deep learning



- State-of-the-art techniques moving from statistical and mathematical transformations for analyzing images to pixel-by-pixel analysis.
- *Deep learning (DL)* requires large amounts of data for it to learn about the context of visual data.
 - After several iterations, the model "learns" to differentiate image features.
- CNN decomposes the image into pixels that are labeled.
 - It uses convolutions to predict the tag according to its input pixel.
 - The accuracy of the prediction should increase with time.





Computer vision capabilities



Object classification

- Identifies/categorizes what is in the image (e.g., cat, dog).
- Output: A label or class for the entire image.
- Example: "This image contains a cat"
- Usage: Image search, simple classification, content tagging


Object identification

- Identifies characteristics and what and where objects are in the image.
- Outputs: Bounding boxes + labels for each object found
- Example: "There's a cat at (x1 y1 x2, y2) and a dog at..."
- Usage: Autonomous driving, security cameras, counting objects.

Classification


Object Detection





CAT

CAT, DOG, DUCK





Computer vision capabilities




Object tracking

- Follows/ Process the location of a specific object across video frames
- Input: A video (or sequential frames) with moving objects
- Output: Path/coordinates of the object over time
- Example: Track a car across security camera footage
- Usage: Surveillance, sports analytics, autonomous vehicles

• Optical character recognition

- Letters and numbers identification to convert it into a set of machine-encoded text
- Input: Text extracted from the image
- Output: A photo, scanned document, or frame with text
- Example: Read the text from a street sign or a scanned book page
- Usage: Document digitization, license plate recognition, translations








OpenCV



- Open-Source Computer Vision Library
- Cross-platform, free to use
- Originally developed by Intel
- Aimed at real-time computer vision
- Contains a wealth of functions and routines for the real-time processing and analysis of images





OpenCV Installation (Python)




- Windows
 - Open a cmd prompt and use the following command (make sure you have pip installed):

pip install opency-python

- Ubuntu
 - · Open a terminal and use the following command:

sudo apt update
sudo apt install -y python3-opencv libopencv-dev

 Please be aware that this is just a basic installation of OpenCV. If you require CUDA or other OpenCV packages such as Aruco, you must install it from source (ubuntu) or using pip in Windows. More information here and here





OpenCV Basics




- Once installed OpenCV, it is possible to start programming in Windows or Ubuntu.
- In this section, only the basics of OpenCV will be shown.
- In the next section, the student will learn to use ROS 2 with OpenCV.
- For the following examples, download the following images and videos from GitHub.



OpenCV

Colour Detection




{Learn, Create, Innovate};



Colour Detection: What is the problem?



• We aim to detect connected regions in the space with a characteristic shape and colour palette.



Example of the problem

Characteristics to exploit

- 1. We can look for patches of certain colours
- 2. We can use size to reject shapes
- 3. We can look for circular shapes in the image




Colour Detection



 The following image, shows a simple colour detection pipeline that can be implemented in OpenCV.

Image Analysis



Colour Spaces


- OpenCV manages different colour
- representations (more than 150), called colour spaces.
- The most widely used are BGR (Blue, Green, Red), HSV (Hue, Saturation, Value) and Gray (Grayscale)
- OpenCV offers conversions amongst these spaces i.e., BGR ↔ Gray and BGR ↔ HSV, etc.
- More information <u>here</u>.



Colour Detection



- BGR (Blue, Green, Red):
 - Default colour format in OpenCV.
 - It is not ideal for colour detection due to the mixing of colour intensities.
- HSV (Hue, Saturation, Value):
 - Hue (H): Represents colour type (0 to 179 degrees in OpenCV).
 - Saturation (S): Concentration/diluting of colour Unsaturated to represent shades of grey and fully saturated (no white component). (0 to 255).
 - Value (V): Brightness or intensity of colour (O to 255).
- Why HSV?
 - More intuitive way to define/describe colours.
 - Used to perform colour-based segmentation



```
img_gray = cv.cvtColor(img,cv.COLOR_BGR2GRAY)
hsv_image = cv.cvtColor(image, cv.COLOR_BGR2HSV)
```



Colour Detection



Colour Range Thresholding


- Now that the colour is on a more practical scale, colours can be filtered by range using the "inRange" function.
- The output is a binary mask.


Basic Idea:

- Check if a pixel [H,S,V] values are within a range i.e., $[H_l,S_l,V_l] \leq [H,S,V] \leq [H_u,S_u,V_u]$
- If the colour is in a range set the pixel to 255 (white)
- Else, set to 0.

```
#Blue Ranges
blue_lower_limit = np.array([90 90, 90])
blue_upper_limit = np.array([110,255,255])

#Blue Mask
blue_mask = cv.inRange(hsv_image, blue_lower_limit, blue_upper_limit)
```









Masks

- A binary image (black & white) used to select parts of another image.
- Usually:
 - White (255): Areas to keep/process.
 - Black (0): Areas to ignore/mask out.
- Example Usage:
 - · Focus operations on areas of interest
 - Create effects and isolate objects
 - Usually obtained by using the "in Pange" function.








Bitwise Operations: AND

- Takes two images (src1 and src2) and performs an AND operation between corresponding pixels.
- If both pixel values are non-zero (i.e., 1), the result is non-zero (i.e., 1). Otherwise, it's zero.
- AND Example:

- In OpenCV, these operations are typically used to apply a mask to preserve specific areas of an image.
- Extract parts of an image that satisfy certain conditions.

result = cv2.bitwise_and(image, image, mask=mask)

If mask used Only pixels where mask is white (255) will be visible in result. The black parts of the mask (0) hide pixels in the output.








Bitwise Operations: OR

- Performs an OR operation between two images.
- If either pixel is non-zero, the result is non-zero.
- OR Example:

Pixel A --> 0 0101010 (binary)
Pixel B --> 0101000 (binary)
----Result --> 0 1 1 1 1010

• In OpenCV, these operations are typically used to Combine two images or regions.

result = cv2.bitwise_or(img1, img2)







Bitwise Operations: XOR

- Performs an XOR operation. If only one of the pixels is non-zero, the result is non-zero.
- If both are zero or both are non-zero, the result is zero.
- XOR Example:

Pixel A --> 0 0 1 0 1 0 1 0 (binary)
Pixel B --> 0 1 0 1 0 0 1 0 (binary)
-----Result --> 0 1 1 1 1 0 0 0

• In OpenCV, these operations are typically used to Highlight differences between two images or regions.

result = cv2.bitwise_xor(img1, img2)








Bitwise Operations: NOT

- Inverts every bit of the image.
- Converts white pixels (255) to black (0) and vice versa.
- NOT Example:

 In OpenCV, these operations are typically used invert a mask or an image. result = cv2.bitwise_not(img1)



Activity 1

Colour Filtering



{Learn, Create, Innovate};



Colour Filtering




Colour Filtering Algorithm

The Following algorithm will Filter the blue and red colours form the video "sample_video.mp4" (you can use your own).

- 1. Convert the base image from RGB to the HSV space
- Filter the image to remove all colours not defined as red or blue, storing the results in two separate images.
 - 1. Use OpenCV's inRange function
 - 2. Suggested values for the colours required

	Red	Blue
Н	0-33	95-110
S	90-255	80-255
٧	130-255	80-255

3. Apply a mask with a bitwise AND operation to view only the colour blue or red.





Colour Filtering



```
import cv2 as cv
import numpy as np
#HSV Values for Red Colour
H red low limit = 0
S red low limit = 95
V red low limit = 130
H_red_up_limit = 5
S red up limit = 255
V red up limit = 255
#HSV Values for Blue Colour
H blue low limit = 95
S_blue_low limit = 90
V blue low limit = 90
H blue up limit = 110
S blue up limit = 255
V blue up limit = 255
if name ==" main ":
    #cap = cv.VideoCapture(2)
    video_path = 'videos/sample_video.mp4'
    cap = cv.VideoCapture(video path)
    if not cap.isOpened():
        print("Cannot open camera")
```

```
#HSV Values for Green Colour
while True:
    # Reading frame from video or webcam
    ret, image = cap.read()
    # if frame is read correctly ret is True
    if not ret:
        print("Can't receive frame (stream end?). Exiting ...")
        break
    k = cv.waitKey(25) & 0xFF
    if k == 27:
        break
    # Convert BGR to HSV
    hsv image = cv.cvtColor(image, cv.COLOR BGR2HSV)
    #Ranges
    red_lower_limit = np.array([H_red_low_limit, S_red_low_limit, V_red_low_limit])
    red_upper_limit = np.array([H_red_up_limit, S_red_up_limit, V_red_up_limit])
    blue_lower_limit = np.array([H_blue_low_limit, S_blue_low_limit, V_blue_low_limit])
    blue_upper_limit = np.array([H_blue_up_limit, S_blue_up_limit, V_blue_up_limit])
    red mask = cv.inRange(hsv_image, red_lower_limit, red_upper_limit)
    blue mask = cv.inRange(hsv image, blue lower limit, blue upper limit)
    #Partial masks applied to the image (AND Function with the image)
    red img result = cv.bitwise and(image,image,mask=red mask)
    blue img result = cv.bitwise and(image,image,mask=blue mask)
    #Full red mask applied to te image
    cv.imshow('image', image)
    cv.imshow('red mask', red img result)
    cv.imshow('blue mask', blue img result)
cap.release()
cv.destroyAllWindows()
```



Noise Rejection



It is common for noise, such as other
objects with the same colour intensity, to
appear in the images after applying certain
operations.

 One of the most common techniques to deal with these artefacts is known as morphological operators

Noisy image

After some initial operations to an original image, we can see some noise in the result that we want to remove







Thresholding


Converts a grayscale image into a binary image. More information

here.

Basic Idea:

- If pixel intensity > threshold, set to max value (e.g., 255).
- Else, set to 0.
- Function: cv2.threshold(source, threshold (0-255), max_value, threshold_type)

```
img_gray = cv.cvtColor(img,cv.COLOR_BGR2GRAY)
ret, mask = cv2.threshold(img_gray, 10, 255, cv2.THRESH_BINARY)
## ret: the threshold used.
## mask: binary image result
```








Morphological Operators



- Morphological operators are defined as a combination between an image and a structuring element.
- The structuring element is usually called "kernel".
- Some operations can be induced by convolving (convolution) the kernel with the original image.
- The most basic morphological operations are Erosion and Dilation.





Morphological Operators



Erosion

- It computes a local minimum over the area of a given kernel.
- Using a mask (kernel), we compute the minimal value of a given area around a pixel, and we replace it with that value.
- The results of this technique are shrinking the larger regions and removing the smallest ones.







Morphological Operators



Dilation

- Analogous to the Erosion.
- It computes a local maximum over the area of a given kernel.
- Using a mask (kernel), we compute the maximum value of a given area around a pixel, and we replace it with that value.
- The results of this technique are in shapes becoming larger and smoothing their edges








Using morphological operators in OpenCV




To apply any morphological operator, we will need to define 3 things.

- 1. The mask/kernel: it will define the area of effect of our operation, for example in an erosion the bigger the mask the smaller will the final shape be.
- 2. Type of operation: OpenCV has functions defining the most common operators, so it is a matter of selecting the suitable option
- 3. Number of iterations: It is common to apply these operations recursively, so OpenC Y allows setting the number of iterations that are going to be made.

More information can be found here.





Activity 2


Morphological Operations



{Learn, Create, Innovate};



- Using the code in Activity 3, morphological operations such as erosion and dilation will be implemented.
- 1. Transform the masked image to grayscale.
- 2. Threshold the image to remove areas with low intensity.
- 3. Erode the image to remove the noise.
- 4. Dilate the image to smooth edges and enlarge the figures.





Colour Filtering



```
import cv2 as cv
import numpy as np
#HSV Values for Red Colour
H red low limit = 0
S red low limit = 95
V red low limit = 130
H red up limit = 5
S red up limit = 255
V red up limit = 255
#HSV Values for Blue Colour
H blue low limit = 95
S blue low limit = 90
V blue low limit = 90
H_blue_up limit = 110
S blue up limit = 255
V blue up limit = 255
if name ==" main ":
    #cap = cv.VideoCapture(2)
    video path = 'videos/sample video.mp4'
    cap = cv.VideoCapture(video path)
    if not cap.isOpened():
        print("Cannot open camera")
```

```
#HSV Values for Green Colour
while True:
    # Reading frame from video or webcam
    ret, image = cap.read()
    # if frame is read correctly ret is True
    if not ret:
        print("Can't receive frame (stream end?). Exiting ...")
        break
    k = cv.waitKey(25) & 0xFF
    if k == 27:
        break
    # Convert BGR to HSV
    hsv image = cv.cvtColor(image, cv.COLOR BGR2HSV)
      langes
    red lower limit = np.array([H red low limit, S red low limit, V red low limit])
    red upper limit = np.array([H red up limit, S red up limit, V red up limit])
    blue lower limit = np.array([H blue low limit, S blue low limit, V blue low limit])
    blue upper limit = np.array([H blue up limit, S blue up limit, V blue up limit])
    red mask = cv.inRange(hsv image, red lower limit, red upper limit)
    blue mask = cv.inRange(hsv image, blue lower limit, blue upper limit)
    #Partial masks applied to the image (AND Function with the image)
    red img result = cv.bitwise and(image,image,mask=red mask)
    blue img result = cv.bitwise and(image,image,mask=blue mask)
```



Colour Filtering



```
#Transform to Grayscale
   bw blue res = cv.cvtColor(blue img result, cv.COLOR BGR2GRAY)
    bw red res = cv.cvtColor(red img result, cv.COLOR BGR2GRAY)
    _ , red_res = cv.threshold(bw_red_res, 30, 255, cv.THRESH_BINARY_INV)
    _ , blue_res = cv.threshold(bw_blue_res, 33, 255, cv.THRESH_BINARY_INV
    kernel = np.ones((5, 5), np.uint8)
    red res = cv.dilate(red res, kernel, iterations=3)
    red res = cv.erode(red res, kernel, iterations=3)
   blue res = cv.dilate(blue res, kernel, iterations=8)
    blue res = cv.erode(blue res, kernel, iterations=8)
    cv.imshow('image', image)
    cv.imshow('red mask', red img result)
    cv.imshow('blue mask', blue img result)
    cv.imshow('blue res', blue res)
    cv.imshow('red res', red res)
# When everything done, release the captured
cap.release()
cv.destroyAllWindows()
```

OpenCV

Blob Detection




{Learn, Create, Innovate};



What is blob?



- A Blob is a group of connected pixels in an image that share some common property.
- Usually are areas in an image that are visually distinct, often brighter/darker.
- In the image, the dark connected regions are blobs, and the goal of blob detection is to identify and mark these regions.
- Useful to detect objects (balls, screws, parts)
- Tracking moving elements.
- Obstacle detection.




Blob = "Binary Large Object"



What is blob?



- Blob detection involves five steps:
 - Thresholding: convert the input image to a binary image through thresholding.
 - Grouping: Find and cluster connected pixels (regions), by making use
 of the "findContours" function. The centre is identified for each of
 the extracted groups of pixels and the value for the centres is
 computed.
 - Merging: Merges all nearby clusters.
 - Radius and centres: Compute radiuses and centres of the blobs
 - Filtering: Keep blobs matching specific criteria:
 - Size
 - Circularity
 - Convexity
 - Inertia ratio (elongation), etc.






Blob Filtering



- Color [0,255]: Compares the intensity of a binary image at the center of a blob to the parameter *blobColor*.
 - blobColor [0,255] to extract dark blobs and light blobs respectively.
- Area [0, maxArea]: Extracted blobs have an area between minArea and maxArea parameters.
- Circularity [0,1]: Extracted blobs have circularity between
 minCircularity and maxCircularity (Circularity of the Circle is 1)
- Ratio [0,1]: Measures the inertia (elongation) of the blob Extracted blobs have this ratio between *minInertiaRatio* and *maxInertiaRatio*.
- Convexity [0,1]: Extracted blobs have convexity (area / area of blob convex hull) between minConvexity and maxConvexity.






Tuning Parameters



Parameter	What it Does	Typical Use
Threshold	Minimum grayscale intensity for detection.	Lower limit
filterByArea	Only blobs within specific area.	Filter noise
filterByCircularity	Select blobs close to circular shape.	Detect more specific shapes such as circles
filterByConvexity	How convex the blob shape is.	Avoid hollow shapes
filterBylnertia	Measures blob elongation.	Exclude thin blobs
filterByColor	Check colour of the blob	Exclude blobs of different colours.

8 SdY Yd n

Simple Blob Detection






Activity 3



Using the code in Activity 4, blob detection will be used to detect the blue blob in a video.

For this activity "sample_video.mp4" must be inside the folder "videos"

- 1. Transform the masked image to grayscale.
- 2. Threshold the image to remove areas with low intensity.
- 3. Erode the image to remove the noise.
- 4. Dilate the image to smooth edges and enlarge the figures.
- 5. Detect blobs
- 6. Print centres and blobs.



```
import cv2 as cv
import numpy as np
# HSV Ranges for detecting BLUE color
H blue low limit = 95
S_blue_low_limit = 90
V blue low limit = 90
H_blue_up_limit = 110
S_blue_up_limit = 255
V blue up limit = 255
blob detec_params = cv.SimpleBlobDetector_Params()
# Thresholds for intensity difference (pixel brightness) during detection
blob_detec_params.minThreshold = 30
blob detec params.maxThreshold = 255
blob_detec_params.filterByColor = True
blob detec params.blobColor = 255
# Filter blobs by area (size in pixels)
blob detec params.filterByArea = True
blob detec params.minArea = 30
                                       # Minimum blob area
blob detec params.maxArea = 10000000 # Maximum blob area
blob detec params.filterByConvexity = True
blob detec params.minConvexity = 0.1
blob detec params.maxConvexity = 1
blob detec params.filterByCircularity = True
blob detec params.minCircularity = 0.5
blob detec params.maxCircularity = 1
blob detec params.filterByInertia = True
blob detec params.minInertiaRatio = 0.5
blob_detec_params.maxInertiaRatio = 1
```

```
# Main Code Execution Starts Here
if name == " main ":
    # Start video capture
    # You can switch to a webcam by using cv.VideoCapture(0)
    video path = 'videos/sample video.mp4'
    cap = cv.VideoCapture(video path)
    if not cap.isOpened():
        print("Cannot open camera or video file")
    # Create the blob detector object with configured parameters
    detector = cv.SimpleBlobDetector create(blob detec params)
    # Main loop to process each frame
   while True
       # Capture frame from video
        ret, image = cap.read()
        # Exit the loop if no frames are returned (end of video)
        if not ret:
            print("Can't receive frame (stream end?). Exiting ...")
            break
        # Check for ESC key press to exit early
        k = cv.waitKey(25) \& 0xFF
        if k == 27:
            break
```

```
# Step 1: Convert image from BGR to HSV color space
hsv image = cv.cvtColor(image, cv.COLOR BGR2HSV)
        # Step 2: Create masks for red and blue colors
# Blue mask: a single range
blue lower limit = np.array([H blue low limit,
S blue low limit, V blue low limit])
blue upper limit = np.array([H blue up limit, S blue up limit,
V blue up limit])
        # Apply color thresholds to create binary masks
blue mask = cv.inRange(hsv image, blue lower limit,
blue upper limit)
        # Step 3: Apply masks to the original image for
visualization
# Apply blue mask
blue img result = cv.bitwise and(image, image, mask=blue mask)
        # Step 4: Convert the masked images to grayscale for
further processing
bw blue res = cv.cvtColor(blue img result, cv.COLOR BGR2GRAY)
        # Step 5: Apply binary thresholding to highlight blobs
in binary images
_, blue_res = cv.threshold(bw_blue_res, 33, 255,
cv. THRESH BINARY)
```

```
# Step 6: Perform morphological operations to clean up noise
    # Create a kernel for morphological operations
    kernel = np.ones((5, 5), np.uint8)
           # Clean blue mask: more aggressive clean-up
    blue res = cv.erode(blue res, kernel, iterations=8)
    blue res = cv dilate(blue res, kernel, iterations=8)
           # Step 7: Detect blobs in the cleaned binary images
    bluekeypoints = detector.detect(blue res)
           # Step 9: Draw keypoints (blobs) on the original image
    view blobs = cv.drawKeypoints(image, bluekeypoints,
   np.array([]),
                                  (255, 255, 255),
   cv.DRAW MATCHES FLAGS DRAW RICH_KEYPOINTS)
           # Step 10: Display the images for
   visualization/debugging
    #cv.imshow('Original Image', image)
    #cv.imshow('Blue Mask Applied', blue img result)
    #cv.imshow('Blue Binary Mask', blue res)
    cv.imshow('Detected Blobs', view_blobs)
       # Step 11: Release resources and close windows when done
cap.release()
cv.destroyAllWindows()
```

{Learn, Create, Innovate};

OpenCV

OpenCV in ROS






Interfacing with ROS



 ROS uses a package called CV Bridge to interface with OpenCV:

\$ sudo apt install ros-humble-cv-bridge

- This package, converts between ROS
 Image messages and OpenCV images.
- More information can be found <u>here</u>.
- OpenCV and cv_bridge come preinstalled on the Jetson.






Interfacing with ROS



 ROS uses a package called CV Bridge to interface with OpenCV:

\$ sudo apt install ros-humble-cv-bridge

- This package, converts between ROS
 Image messages and OpenCV images.
- More information can be found here.
- OpenCV and cv_bridge come preinstalled on the Jetson.



Activity

E' U'9L \$ HE!







Objective

- The objective of this activity is to show the user how ROS and OpenCV can be used together.
- In this activity, some simple feature extraction techniques will be used.

Requirements

The following "usb_cam" node must be installed by the user.

\$ sudo apt install ros-humble-usb-cam

The node can be run using the following command

\$ ros2 run usb_cam usb_cam_node_exe

 This node will access the camera and publish the image into the topic "/image_raw"

Puzzlebot (not necessary)

- If using the Puzzlebot, the user can follow the instruction manual or the presentation
- MCR2_Puzzlebot_Jetson_Ed" to activate the camera using the command

\$ ros2 launch ros_deep_learning video_source.ros2.launch

 The same node can be easily launched from a (launch file) using the following command

\$ ros2 launch puzzlebot_ros camera_jetson.launch.py

 This node will access the camera and publish the image into the topic "/video_source/raw"





Instructions

Create a new package

```
ros2 pkg create --build-type ament_python open_cv_examples
--license Apache-2.0 --dependencies rclpy sensor_msgs
opencv-python cv_bridge ros2launch std_msgs python3-numpy
--node-name opencv_act1 --maintainer-name 'Mario Martinez'
--maintainer-email 'mario.mtz@manchester-robotics.com' --
description 'OpenCV Examples'
```

• Give executable permission to the file

```
$ cd ~/src/open_cv_examples/open_cv_examples/
$ sudo chmod +x opencv_act1.py
```

• Edit the *opencv_act1.py* file

```
open_cv_examples/
    LICENSE
    open_cv_examples
    ___init__.py
    opencv_act1.py
    package.xml
    resource
        open_cv_examples
        setup.cfg
        setup.py
    test
        test_copyright.py
        test_flake8.py
        test_pep257.py
```

```
import rclpy
from rclpy.node import Node
from sensor_msgs.msg import Image
import cv2 as cv
from cv bridge import CvBridge
import numpy as np
class ColorDetectionNode(Node):
    def __init__(self):
        super(). init ('color detection node')
        # Initialize variables
        self.img = None
        self.bridge = CvBridge()
        # Define HSV range for blue color detection
        self.blue_lower = np.array([110, 60, 60], np.uint8)
        self.blue upper = np.array([160, 255, 255], np.uint8)
        # ROS2 Subscriber for raw camera images
        self.subscription = self.create subscription(
            Image,
            '/image raw',
            self.camera callback,
            10
        # ROS2 Publisher for processed images
        self.image pub = self.create publisher(
            Image,
            '/image_processing/image',
            10
        # Timer setup for regular processing
        self.timer = self.create timer(0.1, self.timer callback)
        self.get logger().info('Color Detection Node has started!')
```

```
def camera callback(self, msg):
        """Callback to receive image from the camera and convert to CV2
format.""
        try:
           self.img = self.bridge.imgmsg to cv2(msg, "bgr8")
        except Exception as e:
           self.get_logger().error(f'Conversion error: {e}')
    def timer callback(self):
        """Timer callback for processing the image."""
        # Check if image has been received
        if self.img is None:
             self.get logger().info('Waiting for image data...')
            return
        # Step 1: Reduce noise with Gaussian blur
       blunred img = cv.GaussianBlur(self.img, (9, 9), 2)
        # Step 2: Convert from BGR to HSV color space
       hsv img = cv.cvtColor(blurred img, cv.COLOR BGR2HSV)
       # Step 3: Create binary mask for blue color
       blue_mask = cv.inRange(hsv_img, self.blue_lower, self.blue_upper)
        blue extracted img = cv.bitwise and(self.img, self.img, mask=blue mask)
        # Step 5: Convert extracted blue regions to grayscale
        gray_blue_img = cv.cvtColor(blue_extracted_img, cv.COLOR_BGR2GRAY)
        # Step 6: Threshold grayscale image to binary image
       _, binary_blue_img = cv.threshold(gray_blue_img, 5, 255,
cv.THRESH BINARY)
        # Step 7: Apply morphological operations to clean noise
        kernel = np.ones((3, 3), np.uint8)
        cleaned_img = cv.erode(binary_blue_img, kernel, iterations=8)
        cleaned img = cv.dilate(cleaned img, kernel, iterations=8)
        # Publish the cleaned binary image
        processed_img_msg = self.bridge.cv2_to_imgmsg(cleaned_img,
encoding='mono8')
        self.image pub.publish(processed img msg)
```





```
def main(args=None):
    rclpy.init(args=args)
    color detection node = ColorDetectionNode()
    try:
        rclpy.spin(color detection node)
    except KeyboardInterrupt:
        pass
    finally:
        color_detection_node.destroy_node()
        if rclpy.ok():
            rclpy.shutdown()
if __name__ == '__main__':
    main()
```

 In a new terminal build the new package, source it, and run it

```
ca ~/ros2_ws/
colcon build
source install/setup.bash
```

Start the camera

```
$ ros2 run usb cam usb cam node exe
```

Run the node


```
$ ros2 run open_cv_examples opencv_act1
```


Open RVIZ, or rqt_image_view to view the results

```
$ ros2 run rqt_image_view rqt_image_view
```









8 Sdf Ydi

OpenCV in Puzzlebot - No ROS

Manchester Robotics



OpenCV in Puzzlebot - No ROS



- In the Puzzlebot, the access to the camera used in OpenCV differs from that of a regular camera.
- The Puzzlebot contains an IMX19 Camera module (Raspberry Pi camera) to access such a camera, the user must declare it at the top of the OpenCV Script as stated in the right image.
- The following code shows a simple masking activity on the Puzzlebot. The activity shows a correct way to activate the camera on the Puzzlebot and use it in an OpenCV script.

```
gstreamer pipeline(
sensor id=0,
capture width=1920,
capture height=1080,
display width=960,
display height=540
framerate=30,
flip method=0,
return
     "nvarguscamerasrc sensor-id=%d ! "
     "video/x-raw(memory:NVMM), width=(int)%d, height=(int)%d, framerate=(fraction)%d/1 ! "
     "nvvidcony flip-method=%d ! "
     "video/x-raw, width=(int)%d, height=(int)%d, format=(string)BGRx ! "
     'videoconvert ! "
       ideo/x-raw, format=(string)BGR ! appsink"
         sensor id,
         capture width,
         capture height,
         framerate,
         flip method,
         display width,
         display height,
print(gstreamer_pipeline(flip_method=2))
cap = cv.VideoCapture(gstreamer_pipeline(flip_method=2), cv.CAP_GSTREAMER)
```

```
import cv2 as cv
import numpy as np
def gstreamer_pipeline(
    sensor id=0,
    capture width=1920,
    capture_height=1080,
    display width=960,
    display_height=540,
    framerate=30,
    flip_method=0,
    return (
        "nvarguscamerasrc sensor-id=%d ! "
        "video/x-raw(memory:NVMM), width=(int)%d, height=(int)%d,
framerate=(fraction)%d/1 ! "
        "nvvidconv flip-method=%d ! "
        "video/x-raw, width=(int)%d, height=(int)%d, format=(string)BGRx ! "
        "videoconvert ! "
        "video/x-raw, format=(string)BGR ! appsink"
            sensor_id,
            capture width,
            capture_height,
            framerate,
            flip method,
            display_width,
            display_height,
```

```
#HSV (Hue, Saturation, Value) in OpenCV
#HSV Values for Red Colour
#Red is on the 180 degrees limit in thr HSV so two ranges must be done
#from 160 to 0 and from 0 to 20
H_red_low_limit = 150
S red low limit = 120
V red low limit = 100
H_red_up_limit = 5
S_red_up_limit = 120
V red up limit = 100
#HSV Values for Blue Colour
H blue low limit = 90
S_blue_low_limit = 100
V blue low limit = 70
 blue up limit = 150
S_blue_up_limit = 180
V_blue_up_limit = 100
```

```
if __name__=="__main__":
    print(gstreamer pipeline(flip method=2))
    cap = cv.VideoCapture(gstreamer pipeline(flip method=2), cv.CAP GSTREAMER)
    #window handle = cv.namedWindow('CSI Camera', cv.WINDOW AUTOSIZE)
    if cap.isOpened():
        try:
            #HSV Values for Green Colour
            while True:
                # Reading frame from video or webcam
                ret, image = cap.read()
                # if frame is read correctly ret is True
                if not ret:
                    print("Can't receive frame (stream end?). Exiting ...")
                    break
                k = cv.waitKey(25) & 0xFF
                if k == 27:
                    break
                hsv image = cv.cvtColor(image, cv.COLOR BGR2HSV)
                #Red colour requires 2 ranges because its on the limits of the angles [min H, 179] to
                red lower limit1 = np.array([H red low limit, S red low limit, V red low limit])
                red upper limit1 = np.array([179, 255, 255])
                red lower limit2 = np.array([0, S red up limit, V red up limit])
                red_upper_limit2 = np.array([H_red_up_limit, 255, 255])
                blue_lower_limit = np.array([H_blue_low_limit, S_blue_low_limit, V_blue_low_limit])
                blue upper limit = np.array([H blue up limit, S blue up limit, V blue up limit])
                #Red Masks
                red_mask1 = cv.inRange(hsv_image, red_lower_limit1, red_upper_limit1)
                red mask2 = cv.inRange(hsv image, red lower limit2, red upper limit2)
```

```
blue mask = cv.inRange(hsv image, blue lower limit,
blue upper limit)
                #Partial masks applied to the image (AND Function with the
                masked red1 = cv.bitwise and(image,image,mask=red mask1)
                masked red2 = cv.bitwise and(image,image,mask=red mask2)
                #Full red mask applied to te image
                 red img result = cv.bitwise or(masked red1, masked red2)
                #Full blue mask applied to te image
                blue img result = cv.bitwise and(image,image,mask=blue mask)
                #Transform to Grayscale
                bw blue res = cv.cvtColor(blue img result, cv.COLOR BGR2GRAY)
                bw red res = cv.cvtColor(red img result, cv.COLOR BGR2GRAY)
                   red res = cv.threshold(bw red res, 20, 255,
cv.THRESH BINARY)
                , blue res = cv.threshold(bw blue res, 20, 255,
cv.THRESH BINARY)
                kernel = np.ones((3, 3), np.uint8)
                red res = cv.erode(red res, kernel, iterations=1)
                red res = cv.dilate(red res, kernel, iterations=3)
                blue res = cv.erode(blue res, kernel, iterations=1)
                blue res = cv.dilate(blue res, kernel, iterations=3)
                cv.imshow('image', image)
                cv.imshow('red mask', red img result)
                cv.imshow('blue mask', blue img result)
                cv.imshow('blue res', blue res)
                cv.imshow('red res', red res)
        finally:
            # When everything done, release the captureq
            cap.release()
            cv.destroyAllWindows()
    else:
        print("Error: Unable to open camera")
```







- Run the previous code form a terminal.
- Go to your "opencv_ws" (if applicable)
- In a new terminal build the new package, source It, and run it

\$ python3 activity.py

Thank you

6406ekin/



T&C

Terms and conditions

Stoberich o.

Manchester Robotics



Terms and conditions



- THE PIECES, IMAGES, VIDEOS, DOCUMENTATION, ETC. SHOWN HERE ARE FOR INFORMATIVE PURPOSES ONLY. THE DESIGN IS PROPRIETARY AND CONFIDENTIAL TO MANCHESTER ROBOTICS LTD. (MCR2). THE INFORMATION, CODE, SIMULATORS, DRAWINGS, VIDEOS PRESENTATIONS ETC. CONTAINED IN THIS PRESENTATION IS THE SOLE PROPERTY OF MANCHESTER ROBOTICS LTD. ANY REPRODUCTION, RESELL, REDISTRIBUTION OR USAGE IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF MANCHESTER ROBOTICS LTD. IS STRICTLY PROHIBITED.
- THIS PRESENTATION MAY CONTAIN LINKS TO OTHER WEBSITES OR CONTENT BELONGING TO OR ORIGINATING FROM THIRD PARTIES OR LINKS TO WEBSITES AND FEATURES IN BANNERS OR OTHER ADVERTISING. SUCH EXTERNAL LINKS ARE NOT INVESTIGATED, MONITORED, OR CHECKED FOR ACCURACY, ADEQUACY, VALIDITY, RELIABILITY, AVAILABILITY OR COMPLETENESS BY US.
- WE DO NOT WARRANT, ENDORSE, GUARANTEE, OR ASSUME RESPONSIBILITY FOR THE ACCURACY OR RELIABILITY

 OF ANY INFORMATION OFFERED BY THIRD-PARTY WEBSITES LINKED THROUGH THE SITE OR ANY WEBSITE OR

 FEATURE LINKED IN ANY BANNER OR OTHER ADVERTISING.